



# Distribution amplifiers

# House connection amplifiers

- GaAs push-pull technology
- flexibility provided by plug-in return path dippers
- plug-in inverse equalizer
- plug-in interstage attenuator and equalizer for improving amplifier performance
- weatherproof and RF-screened die-cast housing
- switch-mode power supply unit
- remote powering through input RF port
- transient protection at input and output




Technical specifications		DA12X	DA12XP	DA13X	DA13XP
Type					
Frequency range*			47/75/87-862 MHz		
Return path*			5-30/55/65 MHz		
Input and output impedance			75 Ω		
Gain, 20°C			36 dB		
Flatness			± 0.75 dB		
Input and output return loss			18 dB/40 MHz-1.5 dB/octave		
Input attenuator			0-18 dB		
Input cable equalizer			0-18 dB		
Inverse cable equalizer			0-9 dB in 1 dB step		
Noise figure			max. 6 dB		
Output level CTB (EN50083-3)**		108 dBμV (42 ch.)		111 dBμV (42 ch.)	
Output level CSO (EN50083-3)**		110 dBμV (42 ch.)		112 dBμV (42 ch.)	
Mains voltage	24-65 V~ 50 Hz	187-250 V~ 50 Hz	24-65 V~ 50 Hz	187-250 V~ 50 Hz	
Power consumption	max. 12.5 W	max. 11 W	max. 15.5 W	max. 13.5 W	
Current consumption	24 V AC 42 V AC 65 V AC	0.77 A 0.49 A 0.36 A	- - -	0.94 A 0.59 A 0.43 A	- - -
Loss in internal input test point (bi-directional)			-20 ± 2.0 dB		
Loss in internal output test point (directional)			-20 ± 0.5 dB		
Input connector***			PG11 or F		
Output connector			F		
Test point connectors			F		
Operating temperature range			-20° ÷ + 50° C		
Dimensions		180x132x76 mm (main body); 213x132x76 mm (with fixing ears)			
Weight (packed)	1.6 kg	1.7 kg	1.6 kg	1.7 kg	

\* frequency range depends on inserted plug-in diplexer

\*\* output level (CTB, CSO) is measured with 6 dB interstage equalizer

\*\*\* the amplifier is available with input connector PG11 thread or F female


All parameters are measured with links pl 01-00 instead of return path dippers; JXP-0 instead of input attenuator, cable equalizer, cable inverse equalizer; interstage attenuator and cable equalizer.






# Distribution amplifiers

# House connection amplifiers



**Structure diagram of DA1X6X**






# Distribution amplifiers

# House connection amplifiers

## Structure diagram of DA1X7X



## Ordering notes

<b>Band</b>	no return path	2 x pl 01-00
	30/47 MHz	2 x pd 03-30 (pd 04-30)
	55/75 MHz	2 x pd 03-55 (pd 04-55)
	65/87 MHz	2 x pd 03-65 (pd 04-65)
<b>Return path</b>	0 dB passive	pl 02-00
	20/25 dB gain 30 MHz, variable adjustments	pr 04-30
	20/25 dB gain 55 MHz, variable adjustments	pr 04-55
	20/25 dB gain 65 MHz, variable adjustments	pr 04-65
	20/25 dB gain 30 MHz, plug-in adjustments	pr 05-30, JXP-XX
	20/25 dB gain 55 MHz, plug-in adjustments	pr 05-55, JXP-XX
	20/25 dB gain 65 MHz, plug-in adjustments	pr 05-65, JXP-XX
<b>Input adjustments</b>	cable simulator 0÷9 dB by 1 dB step	JXP-XX
	attenuator 0÷20 dB by 1 dB step (for DA1X6X only)	JXP-XX
	equalizer 0÷20 dB by 1 dB step (for DA1X6X only)	JXP-XX
<b>Interstage</b>	attenuator 0÷10 dB by 1 dB step	JXP-XX
	equalizer 0÷9 dB by 1 dB step	JXP-XX

<b>Ordering number</b>	
<b>DA126</b>	11848
<b>DA126-A</b>	11878
<b>DA126P</b>	11850
<b>DA126P-A</b>	11880
<b>DA127</b>	11849
<b>DA127-A</b>	11879
<b>DA127P</b>	11851
<b>DA127P-A</b>	11881
<b>DA136</b>	11852
<b>DA136-A</b>	11882
<b>DA136P</b>	11854
<b>DA136P-A</b>	11884
<b>DA137</b>	11853
<b>DA137-A</b>	11883
<b>DA137P</b>	11855
<b>DA137P-A</b>	11885